"MKKLA! MUND.CO.UK www.MarkLamond.co.uk Honda Integra DC2 SiR-G (JDM) **Instrument Cluster Pinout** All Views From Rear (Wire Side) Of Connector

Connector "C" used on A/T models has been omitted.

WN	·MA	6.		4	h		
				ww.MarkLar		_	
		Honda Integra DC2 SiR					
				strument Clu			
				From Rear (Wi C" used on A/T i			
		Connecto		J used on A/T i	model	5	
						(
	13 Way - Left S	Side of Dashboard					
					D1		
					D2		
				M II	D3		
				Yellow		L	
	Ground	GND		Black	D5	I	
· · · ·	Engine Coolant Temperature	ECT		Yellow/Green		ľ	
	Engine ocolant remperature	201		T CIIOW/ CIECIT			
					D8		
	Alternator Warning Light	ALT		White/Blue			
	Catalyst Temperature Light	CAT		Red			
	Oil Pressure Indicator Light	OIL-P		Yellow/Red		I	
	Check Engine Light	CEL		Green/Orange			
	Tachometer Input	RPM		Blue	D13	I	

▰

www.MA

15 Way - Right Side of Dashboard									
Driver's Seatbelt Indicator Light	BELT		Red/Blue	B1					
Door Open Indicator Light	DOOR		Green/Red	B2					
Fuel Gauge	FUEL		Yellow/White	B3					
Low Fuel Indicator Light	LO-FUEL		Blue/White	B4					
				B5					
Vehicle Speed Sensor Signal	VSS		Blue/White	B6					
Boot Open Indicator Light	BOOT		Green	B7					
ABS Indicator Light	ABS		Blue/Red	B8					
Ground	GND		Black	B9					
Cluster Illumination Supply	ILLUM		Red/Black	B10					
+12v Supply From Ignition Switch	+12v IG1		Black/Yellow	B11					
				B12					
Left Turn Indicator Light	TURN-L		Green/Blue	B13					
Right Turn Indicator Light	TURN-R		Green/Yellow	B14					
High Beam Indicator Light	HIGH-B		Red/Green	B15					
Brake Warning Indicator Light	BRAKE		Green/Red	B16					
			h-						

5 Way - SRS - Far Right Side of Dashboard							
SRS Indicator Circuit Supply	+12v IG1		Yellow	A1			
				A2			
SRS Indicator Ground	GND		Black	A3			
				A4			
SRS Indicator Input	SRS		Blue	A5			
		_					

Notes:

Please note that colour codes can sometimes vary between vehicles, however the function of each pin is always the same

2006 © Mark Lamond 2006 WWW.MARK,

LAMOND