MAKLAI 'MU.CO.UK www.MarkLamond.co.uk

Honda CRX/Civic EE8/EE9

Instrument Cluster Pinout

All Views From Rear (Wire Side) Of Connector

WH	·MA	D .	LAI	h			
- 4			www.MarkLai				
		Honda CRX/Civic E					
In .	" . A.	Instrument Cluster					
	7///	All Vie	ws From Rear (Wi	re Sid			
TV L	4	b .		77			
	12 Way - C 709 - A - I	Left Side of	Dashboard				
4	Left Turn Indicator	L TURN	Green/Blue	A1			
	High Beam Indicator	H BEAM	Red/Blue	A2			
	Coolant Temp Sensor	TEMP	Yellow/Green				
	Cluster Illumination Supply	ILLUM	Red/Black				
	Brake Warning Indicator	BRAKE	Green/Red				
	Oil Pressure Warning Indicator	OIL-P	Yellow/Red				
	Check Engine Lamp	CEL	Green/Orange				
	Hazard Warning Indicator	HAZARD	Green/White				
	Batt Supply For Hazard Warning	+12v BAT	White/Green				
	IG-1 Feed For Alternator Warning	+12v IG-1	Black/Yellow				
	Alternator Warning Indicator	ALT	White/Blue				
	Tachometer Input	TACHO	Blue	A12			



			An .				
8 Way - C 710 - B - Right Side of Dashboard							
Ground	GND		Black	B1			
VSS Signal OUTPUT	VSS		Yellow/Red	B2			
Trunk Open Switch Input	TRUNK		Green/Black	B3			
ALB Warning Indicator	ALB		Blue/Red	B4			
				B5			
Fuel Gauge Input	FUEL		Yellow White	B6			
IG-2A Switched Supply	+12v IG-2A		Yellow	B7			
Right Turn Indicator	R TURN		Green/Yellow	B8			



5 Way - C ??? - Middle of Dashboard					
				C1	
				C2	
Low Fuel Indicator	LO-FUEL		Green/Red	C3	
				C4	
				C5	

WWW.MARKIAMAN.



Please note that colour codes can sometimes vary between vehicles, however the

function of each pin is always the same.

© Mark Lamond 2006

WW.MA

MoND.Co. RALAMOND.CO.U lark L.